Step 1 - Turn off your device.

Step 2 – Connect your device to your PC using USB C able.

Step 3- Now from the Extracted Fastboot folder, l ook for Run Me.bat file and Run it, following scre en will appear:Fastboot Tool Screen Shot

Step 4 – Now type following command to boot your d evice into fastboot mode:

adb reboot bootloader

This command will boot your device into fastboot m ode which we required to flash recovery file to de vice.

Step 5 – Now type the following command on command prompt:

fastboot flash recovery custom-recovery-file-name.i mage

Replace “custom-recovery-file-name.image” with your recovery file name.

Step 6 – Type follow to reboot the deivce

fastboot reboot

Now your device will reboot and it will be started normally. Now as you’ve installed custom recovery , now you are free to install Roms, mods and much more.